



www.TheaterThings.com

1-877-285-3522


Tools

1. Razor Knife or Box Cutter
2. Straight Edge




Application

Cut the flock in to 4 pieces corresponding to the top, bottom, left and right dimensions of your screen. Make sure to allow about 4 inches of extra at each end of the pieces. For example: your screen is 100 inches wide by 54 inches high, cut 2 pieces 108 inches and 2 pieces 62 inches.



Using your knife, cut carefully through the paper backing about 4 inches from each end of the piece of flock you're working with. Make sure not to cut through the flock itself, the 4 inch long pieces of protective backing will stay on till the end of the operation. Peel the main piece of backing away from the flock and apply the flock to the appropriate edge of the screen. Repeat this procedure with the remaining 3 pieces of flock.



You should now have 2 pieces of flock with the backing on at each corner of the screen, pull these pieces snug and overlap one on top of the other.



Using your straight edge as a guide, cut from the inside corner to the outside corner of the flock applying enough pressure to cut through both layers of flock. Be careful not to cut the screen surface itself. Discard the scrap pieces of flock, peel the remaining backing off the previously applied flock and lay the 45 degree edges together for a nice clean corner.

